

## CITROEN GRAND C4 PICASSO

Our ref: H0466

### 2 BOOT LINER MODELS

Both: 3<sup>rd</sup> Row Folded

Either 2<sup>nd</sup> row slid as far back to the tailgate

OR 2<sup>nd</sup> row slid as far forward



Packing requirements

#### BOOTLINER

- Minimum of 22 self-adhesive loop fastener tabs  
2 x 465mm cut lengths of self adhesive loop fasteners.

#### REAR DOOR COVER

- Minimum of 25 self-adhesive loop fastener tabs  
1 x 400mm cut lengths of self adhesive loop fasteners.

### IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly any residue with a separate clean dry cloth.

**NOTE:** The adhesive takes 24hrs to reach full adhesion – do not touch during this time. In cold weather we advise you fit the liner in a warm environment (i.e. run the car till the interior is warm)

### PREPARATION

- Remove the load space cover cassette
- *Please refer to photographs over page for the following:*
- **Photo A:** Ensure the 3<sup>rd</sup> row seat foot wells have been covered with the drop down flaps.
- **Photo B:** Unlock the 3<sup>rd</sup> row seat belts and secure as shown.

### FITTING

#### BASE PANEL

- Position the base of the liner snugly into place. The hook fastener will attach directly to the carpet.
- Fasten the 4 ties (located at the tailgate end) to the corresponding "D" rings.

## FRONT PANEL

- Pass the hook & loop fastener straps around the headrest posts and fasten close to the liner.
- REAR PLUS / SPLIT FRONT versions: The hook fasteners will attach directly to the carpet.

## SIDE PANELS

- Position the side panels snugly into place, and fasten ties.
- Use the self adhesive loop fasteners to attach to the plastic.

## OPTIONAL EXTRAS

Rear Plus version liners – you will need to unfasten the headrest straps before you attempt to fold your 2<sup>nd</sup> row seats flat!

Rear Door Cover: Use the self-adhesive loop fasteners supplied to attach the sides to the plastic panels.

