

TOYOTA AVENSIS ESTATE 2009 to 2018

Our ref: Ho482

PACKING REQUIREMENTS
BOOTLINER
Requires no additional fixings
TAILGATE COVER
Requires no additional fixings



Photo shows additional Bumper Flap



Photo A

PREPARATION

- Remove the load cover and safety net cassettes. They can be replaced later.
- Remove any Luggage hooks from the Trunk Rails and store away.
- Remove the two plastic recess side panels. They can be replaced later: see Photo A

Photo A

FITTING

BASE

- Place the liner into the car and fit the base snugly into place. The hook fastener welds on the reverse face of the base panel will attach directly to the carpet.

FRONT (Has the Hatchbag label)

- Pass the hook & loop fastener straps around each corresponding headrest posts, and fasten close back upon themselves. The hook fastener welds on the reverse face of the panel will attach directly to the carpet.

SIDES

- Ensure you position the bound slots over the recess panel's plastic location brackets. Feed the luggage hooks through the cutouts. Then carefully position the side panels snugly into place.
- The hook fasteners on the reverse face of the liner will attach directly to the carpet.

If you intend to frequently remove/fit the Boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent use fitting kit" – ask our sales team or see our on-line "factory shop".

- "Rear Plus" versions only: The ties attach to the rear seat's chrome locking bars.
- Replace the two plastic recess side panels. You may also replace the load cover and safety net cassettes now.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS**

TAILGATE COVER (Optional Extra)

- The hook fastener welds on the reverse face of the door cover will attach directly to the carpet.

