

### **VOLKSWAGEN UP! - 2012 Onwards**

Our ref: Ho619

### Please read the following guide to chose the correct version

H0619-FNO

# NO FALSE FLOOR





This version does not have a false floor



H0619-FOUT

# FALSE FLOOR OUT





This version has a false fitted as an accessory. Please remove the false floor to reveal the plastic moldings on the sides.



H0619-FIN

## **FALSE FLOOR IN**



▲ NOT AVAILABLE! (X)



This version has a false fitted as an accessory. We do not accommodate the false floor in, and in a raised position.

