

AUDI Q5 - 2016 Onwards AUDI SQ5 - 2017 Onwards

OUR REF.: Ho652

FITTING KIT CONTENTS :

- BOOT LINER
 - 2x 440 mm 30mm wide self-adhesive loop fastener
- TAILGATE COVER
 - 18 x self-adhesive loop fastener



Photo shows boot liner with rear split for Shape I



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Vehicles with adjustable upper rear seats : ensure they are reclined. (image A)



STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image B)



STEP 3. FITTING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and the seat panel. (image C)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (image D). Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)

STEP 4. FITTING THE BACK

- Stick the 400mm loop fastener strip onto the chrome located on both sides of the lock at the tailgate end of the boot. Fasten the boot liner to it using the hook fastener welded onto it. (Image E)



STEP 5. FITTING THE SIDES

- Position the recess sections of the sides so they fit snugly into place. The hook fastener welded onto the reverse face of the boot liner will attach directly to the carpet. (Image F & G)
- Fasten the hook fastener sewn onto the top edge of the boot liner sides directly onto the carpet along the top edge of the carpeted boot sides. (Image H & I)



IMAGE F



IMAGE G



IMAGE H



IMAGE I



SHAPE 2

Please note the nearside net will sit behind the boot liner, and the offside net will be exposed and usable. (see image G & I)

Please also note we have amended this boot liner to include 2 mesh panels that accommodate the vents in the boot. (*Not shown in images F*)

OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 6A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)



STEP 6B. TAILGATE COVER



Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 6C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 6D. FLOOR EXTENSION

The Bootliner extension provides superior protection for the rear seats when purchased with a REAR PLUS option. (Image 6)

- Bootliner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- It offers no protection to the rear doors
- Attach the Bootliner Extension to the main bootliner (Image 6)

The Seat Flap 6A, The Bumper Flap 6C & The Floor Extension 6D cannot be added at a late date

STEP 6E. FREQUENT USE KIT

- If you frequently remove/install your boot liner from/to your vehicle, please note that the carpet will “fluff” up – we offer an alternative Frequent Use Fitting Kit. These tabs are placed between the boot liner and the boot carpet. (image 7 & 8)

The Frequent Use Kit is an accessory available to purchase from our on-line store

